

DriftClip® DSLS Installation Instructions

Vertical Deflection & Drift @ Bypass Structure

Large Step Bushing
(Engineered for PAF to structure)

Standard Step Bushing
(Engineered for #12 screw to stud)

DriftClip® DSLS

Step Bushings are pre-installed. Do not remove unless otherwise indicated.

Structural Member

Refer to Design Drawings for fastener type, size, and amount

Stud

Install screws using a screw gun that does not exceed 2,500 rpm.

Screw gun must be equipped with torque limiting clutch to avoid fastener overdrive.

#12 Screw

For Installation, Technical, or Submittal questions, contact TSN at (888) 474-4876.

Email us at tsn@steelnetwork.com.

Visit www.steelnetwork.com and discover the value of each TSN Solution.