

StiffClip® HE Installation Instructions: Header Connector



StiffClip® HE(L) or HE(H)
(for use with typical boxed header)

StiffClip® HE(S)
(for use with JamStud® header)

Install four (4) StiffClip HE per opening. Refer to design drawings for fastener type and quantity required.

Window or Door Jamb

Attach StiffClip HE to jamb with required number of screws.

Window or Door Jamb

Boxed Header

JamStud® Header

StiffClip® HE(L) or HE(H): Place boxed header on shelf tabs of each StiffClip HE.

StiffClip® HE(S): Place JamStud® header on shelf tabs of each StiffClip HE.

Boxed Header

Attach clip to header with required number of screws.

Boxed Header

Attach shelf ledge to header with required number of screws.

Boxed Header

Attach bottom angle to jamb with required number of screws.

Consider using TSN's JamStud® in place of all window or door jamb studs for added quality. For Installation, Technical or Submittal questions, contact The Steel Network at **(888) 474-4876** or email us at **support@steelnetwork.com**.

Visit **www.steelnetwork.com** and discover the value of each TSN solution.

Rev 2