



Material Properties

A1003 / A1003M ST50H [ST340H], Grade 50 (340), 50ksi (340MPa) minimum yield strength, 65ksi (450 MPa) minimum tensile strength, G-60 (Z180) hot-dipped galvanized coating; or equivalent.

Flat Strap Product Profile (For StiffWall®)						
Section	Width (D)	Gauge	Design Thickness (t)	Min. Steel Thickness ($t_{(min)}$)	Area	Weight
	(in)		(in)	(in)		
FS400-54, 50 ksi	4	16	0.0566	0.0538	0.226	0.770
FS600-54, 50 ksi	6	16	0.0566	0.0538	0.340	1.156
FS800-54, 50 ksi	8	16	0.0566	0.0538	0.453	1.541
FS800-68, 50 ksi	8	14	0.0713	0.0677	0.570	1.941
FS1000-68, 50 ksi	10	14	0.0713	0.0677	0.713	2.426
Flat Strap Product Profile (For Bridging)						
FS200-43, 50 ksi	2	18	0.0451	0.0428	0.090	0.307
FS300-43, 50 ksi	3	18	0.0451	0.0428	0.135	0.460
FS300-54, 50 ksi	3	16	0.0566	0.0538	0.170	0.578

Table Notes:

- Section properties and capacities are calculated in accordance with AISI-NASPEC 2007.
- Structural framing is produced to meet or exceed ASTM C955, A653, and A1003.
- Non-Structural framing is produced to meet or exceed ASTM C645, A653, and A1003.
- Galvanized sheet steel meets or exceeds requirements of ASTM A924 & A1003.

Order Information for StiffWall Flat Strap

The Selection of flat strap for StiffWall is simplified to 6 strap types, with load capacity factored using standard 12ga (97mil) strap track (see Step-By-Step Design Procedure on TSN's StiffWall product page for Allowable Flat Strap Capacity Chart). Flat Strap is cut to length with square ends, and will need to be cut to final length in the field. To determine the length of the flat straps, follow these simple steps:

1. Find the width (A) and the height (B) of the StiffWall.
2. Then, use the following formula to determine the length of the strap: $A^2 + B^2 = C^2$
3. Next, take the square root of C, round up to the nearest whole number and add 1

This will result in a length in feet that you can work with. If C equals a whole number, you may want to add 2 to make sure the length is enough.

Example: 8' wall height with a width of 16' would look like this: $(8 \times 8) + (16 \times 16) = \sqrt{320} = 17.88$
Round up to 18' and add 1' for a strap length of 19'.

Some points to remember concerning Flat Strap:

- Flat strap can not be installed, un-installed, and then re-installed (A new piece of strap is required).
- Strap must be pulled tight after a gravity load above has been applied.
- Do not fasten the strap to the infill studs between the columns.
- Straps should not be spliced without an approved design.
- Four (4) pieces of strap are required in each StiffWall (If there are 10 StiffWall shear walls, 40 pieces of flat strap will be necessary)